

More information about the cleaning of your hearing protectors and the use of the cleaning products can be found in the user manual.

Hygiene kit (Art.no. 891012)

Elacin Hygiene kit for easy daily cleaning of hearing protectors.

This kit holds the following products:

- + 1 wax remover tool + brush
- + 1 towel (for daily and monthly cleaning)
- + 2 sprays
- + 4 brushes
- + 1 user manual



At the end of every working day, spray a little disinfectant spray on the hearing protectors and use the brush to remove excess dirt. Then use the wax remover tool supplied, if necessary, to remove ear wax from the sound canal.

Finally, dry the hearing protectors using the towel and store them in the case provided.

